



PCB COMPONENT VIEW

PANEL BACKSIDE VIEW

RES18 VCM Panel Wiring

UPPER SECTION

- G..... In
- H..... Wiper VC pot
- K..... Centre Top switch
- L..... Right Top switch
- J..... Centre Bottom switch
- Connect Out socket to Centre Top of switch, thru a R220 resistor
- Connect VC In socket to Bottom Right of switch
- Connect Centre Bottom & Right Bottom of switch w/ 330K resistor

MIDDLE SECTION

- P..... Out
- B..... In 2
- A..... In
- C..... VC In socket
- D..... Wiper VC pot

LOWER SECTION

- M..... Out 1
- N..... Out 2
- E..... In 2
- F..... In 1
- S..... VC In socket
- R..... Wiper VC pot
- +12V and 0V..... outer slugs of the VC pots
- X..... +12V PS
- W..... 0V PS
- Z..... -12V PS
- Y..... +6V Unused !

07 July 2009

WAVE MULTIPLIERS

